

▼ Installation Instructions - ViewGuard™ Crystal Clear High-Gloss Screen Protector



1. Ensure your workspace is clean and dust free. Slightly dampen the enclosed microfiber cleaning cloth and carefully wipe the surface of the LCD display to remove dust, debris and smudges. Wipe any excess dampness off the screen with a dry section of the microfiber cleaning cloth.



2. Carefully remove the protective plastic covering from the rear of the screen protector by pulling the tab labeled "Step 1" while using a firm flat edge (e.g. credit card or license) to evenly apply the silicone adhesive backing to the display.



3. Remove any excess air bubbles by using a firm flat edge to work the bubbles toward the edge of the screen protector. Peel back the screen protector and use cellophane tape to remove any dust or debris caught underneath the screen protector. Trapped air bubbles will slowly dissipate over 48 hours.



4. Carefully remove the protective plastic covering from the front of the screen protector by pulling the tab labeled "Step 2" and the installation of your ViewGuard™ product is complete.



Maintenance & Care: Please retain your microfiber cleaning cloth in order to clean your ViewGuard™ product in the future. Slightly dampen the microfiber cloth and carefully wipe the surface of the ViewGuard™ product to remove dust, debris and smudges.

▼ Usage Recommendations

• Please check with the LCD display manufacturer prior to installation to ensure this product will not damage your display. Only use ViewGuard™ products for their intended use. Additional information about this product and other ViewGuard™ products can be found online at www.BuyViewGuard.com.